

# **OPTOTRONIC** Wireless Intelligent – Casambi NFC LP

Compact constant current LED driver – Dimmable



### Areas de aplicação

- Indicado para uso em luminárias com possibilidade de definição da corrente
- Instalação em sistemas de iluminação de emergência conforme IEC 61347-2-13, anexo J
- Indicado para instalações de interior com SELV
- Adequado para luminárias de classes de proteção I e II

# Benefícios do produto

- Versatile CASAMBI window driver due to flexible output characteristic

## Características do produto

- Tensão de alimentação: 220...240 V
- Frequência da linha: 0 Hz | 50 Hz | 60 Hz
- Tensão da linha: 198...264 V

#### Informa � � es sobre aplica � � es

Para obter mais informa � � es sobre aplica � � es e gr � ficos acesse a ficha t � cnica do produto.

#### Texto ficha técnica

- Download Casambi app from App store or Google play. For the correct functioning of the Casambi app refer to the Casambi website: http://www.casambi.com.
- The Casambi App is provided to you by Casambi. OSRAM shall have no liability for the Casambi app and does not make any representations, express or implied, about the availability and/or performance of the Casambi app.
- The Casambi cloud services are provided to you by Casambi. OSRAM shall have no liability for the Casambi cloud services and does not make any representations, express or implied, about the availability and/or performance of the Casambi cloud services.
- OSRAM shall have no liability for and does not make any representations, express or implied, about the connectivity of Casambi ready products of OSRAM with any other Casambi ready products.
- There are two places in the app where you can unpair a Casambi enabled device from a network.1. Go to the 'Luminaires' tab and tap 'edit'. Unpair a luminaire by tapping the ("X") that will appear in the corner of the relevant luminaire icon. You can also double-tap a luminaire icon to open the "luminaire properties" screen, and then scroll down and tap 'Unpair device'.2. Go to the "Nearby devices" screen found under the 'More' tab. Tap on the device you wish to unpair and select 'Unpair device'. This will unpair the luminaire if you have modification (administrator) rights to the network.If you don't have the modification rights to the network that the device is paired to then you need to have access to the devices power switch to be able to unpair. Tap on the device you wish to unpair and select 'Unpair' screen. Tap on the 'Start' button and an orange "Time bar" will appear and start to move across the screen. During the time it takes the bar to move across the screen, flick the power switch off and back on again. This should unpair the device. If unpairing succeeds then there is a message that luminaire has been unpaired. If it does not succeed then try again but switch the power off and on again more slowly (This may be needed for devices that use an additional power supply; such as a CBU-PWM4). If unpairing continues to be unsuccessful then it is probably the case that the power switch is not correct for the device you are trying to unpair.

#### Vendas e suporte t�cnico

Vendas e suporte t�cnico www.osram.br

#### Ecodesign regulation information:

Intended for use with LED modules.

The forward voltage of the LED light source shall be within the defined operating window of the control gear in all operating conditions including dimming if applicable.

Separate control gear and light sources must be disposed of at certified disposal companies in accordance with Directive 2012/19/EU (WEEE) in the EU and with Waste Electrical and Electronic Equipment (WEEE) Regulations 2013 in the UK. For this purpose, collection points for recycling centres and take-back systems (CRSO) are available from retailers or private disposal companies, which accept separate control gear and light sources free of charge. In this way, raw materials are conserved and materials are recycled.

# Retrata � � o

Sujeito a altera � � o sem pr � vio aviso. Sempre utilize a vers � o mais recente.

May 17, 2024, 15:37:19